

EFS-99 Instructions

Left Side



1. Remove several fairing fasteners to gain access to factory engine mount bolt and remove bolt.

2. Install bracket marked L and M10x80 bolt, torque to factory spec



3. Attach slider with M10X50 Bolt
4. Install fairing fasteners

Right Side



- 1. Remove factory engine mount bolt**
- 2. Install bracket marked R use M10X80 bolt and torque to factory spec**
- 3. Install slider with M10x50 bolt**
- 4. Install fairing fasteners**

We highly advise having a trained professional install sliders.

Intuitive Race Products Vista, Calif.