



Front Axle Sliders™

Congratulations! You have just purchased the world's finest Front Axle Sliders. These sliders have been designed to offer unsurpassed protection to your motorcycle in the unfortunate event of a crash or tip over.

Important: These Front Axle Sliders are designed to fit the hollow front axle of your motorcycle. This kit has separate left and right pieces (*left and right while sitting on the bike*). We recommend using a non-permanent thread lock compound.

Instructions:

1. Unscrew the shorter piece (right-side) completely from the stud.
2. The left-side piece should be hand-tight on the stud. (You may want to remove it and add some non-permanent thread lock compound)
3. Insert stud through the left side of the motorcycle until it is fully seated against fork leg (may require a little force).
4. Screw the right slider with bushing inside onto stud until it is hand-tight (you may have to hold the left side with a screwdriver).
5. Use a large flat tip screwdriver to tighten slider. A ¼ to a ½ turn should be enough. DO NOT OVERTIGHTEN.

Included in this kit:

- (1) 8mm x 267mm Stud
- (2) Threaded Aluminum bushings (pressed into plastic)
- (2) Plastic Front Axle Sliders
 - Left (longer piece)
 - Right (shorter piece)

Part No. FAS-1

Phone: (949) 586-0514
Web: <http://www.IntuRace.com>

Front Axle Sliders™

Congratulations! You have just purchased the world's finest Front Axle Sliders. These sliders have been designed to offer unsurpassed protection to your motorcycle in the unfortunate event of a crash or tip over.

Important: These Front Axle Sliders are designed to fit the hollow front axle of your motorcycle. This kit has separate left and right pieces (*left and right while sitting on the bike*). We recommend using a non-permanent thread lock compound.

Instructions:

1. Unscrew the shorter piece (right-side) completely from the stud.
2. The left-side piece should be hand-tight on the stud. (You may want to remove it and add some non-permanent thread lock compound)
3. Insert stud through the left side of the motorcycle until it is fully seated against fork leg (may require a little force).
4. Screw the right slider with bushing inside onto stud until it is hand-tight (you may have to hold the left side with a screwdriver).
5. Use a large flat tip screwdriver to tighten slider. A ¼ to a ½ turn should be enough. DO NOT OVERTIGHTEN.

Included in this kit:

- (1) 8mm x 267mm Stud
- (2) Threaded Aluminum bushings (pressed into plastic)
- (2) Plastic Front Axle Sliders
 - Left (longer piece)
 - Right (shorter piece)

Part No. FAS-1

Phone: (949) 586-0514
Web: <http://www.IntuRace.com>