



Frame Sliders

Congratulations on purchasing the world's finest frame sliders. The frame sliders are to be mounted to your upper engine mounts. Refer to your service manual before performing this installation. Loosen the pinch bolt holding your left upper engine mount, remove the allen bolt (8mm head). Reinstall using the supplied bolt, torque to factory specs. Tighten the pinch bolt. Remove the right side (10mm head) engine mount bolt. There will be some cutting of your bodywork necessary in order to mount the right side. It is recommended to use a small drill bit to establish a pilot hole. Then use a 1 7/8" or 2" hole saw to cut the bodywork. Reinstall and torque to factory specifications. Replace only one side at a time. Refer to your service manual for more detailed instructions.

Part No. FS-4

Phone: (949) 586-0514
Web: <http://www.IntuRace.com>