



Frame Sliders

Congratulations! You have just purchased the world's finest frame sliders. These sliders have been designed to offer unsurpassed protection to your motorcycle in the unfortunate event of a crash or tip over.

Important: These Frame Sliders are designed to fit specific engine mounts of your motorcycle. This kit has separate left and right pieces (*left and right while sitting on the bike*). The notched slider is to be used with the 80mm bolt on the left side. It is highly recommended that you refer to your service manual before performing this installation. It is also recommended that a non-permanent thread lock compound be used.

Instructions:

1. Remove the left-side engine mount bolt.
2. Install the notched piece of plastic using the new 10 x 80mm (shorter) bolt supplied in this kit. Align the slider so the cut out clears the fairing.
3. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.
4. Loosen the pinch bolt on the right side.
5. Remove the right side engine mount bolt.
6. Install the piece of plastic using the new 10 x 90mm (longer) bolt supplied in this kit.
7. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.
8. Tighten the pinch bolt to the factory specifications.

Included in this kit:

- (2) Bolts
 - 1 - 10 x 80mm (left)
 - 1 - 10 x 90mm (right)
- (2) Aluminum bushings (pressed into plastic)
- (2) Plastic Frame Sliders
 - Left (notched piece)
 - Right (shorter piece)

Part No. FS-54

Phone: (760-598-2105)
Web: <http://www.IntuRace.com>



Frame Sliders

Congratulations! You have just purchased the world's finest frame sliders. These sliders have been designed to offer unsurpassed protection to your motorcycle in the unfortunate event of a crash or tip over.

Important: These Frame Sliders are designed to fit specific engine mounts of your motorcycle. This kit has separate left and right pieces (*left and right while sitting on the bike*). The notched slider is to be used with the 80mm bolt on the left side. It is highly recommended that you refer to your service manual before performing this installation. It is also recommended that a non-permanent thread lock compound be used.

Instructions:

1. Remove the left-side engine mount bolt.
2. Install the notched piece of plastic using the new 10 x 80mm (shorter) bolt supplied in this kit. Align the slider so the cut out clears the fairing.
3. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.
4. Loosen the pinch bolt on the right side.
5. Remove the right side engine mount bolt.
6. Install the piece of plastic using the new 10 x 90mm (longer) bolt supplied in this kit.
7. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.
8. Tighten the pinch bolt to the factory specifications.

Included in this kit:

- (2) Bolts
 - 1 - 10 x 80mm (left)
 - 1 - 10 x 90mm (right)
- (2) Aluminum bushings (pressed into plastic)
- (2) Plastic Frame Sliders
 - Left (notched piece)
 - Right (shorter piece)

Part No. FS-54

Phone: (760-598-2105)
Web: <http://www.IntuRace.com>