



Frame Sliders

Congratulations! You have just purchased the world's finest frame sliders. These sliders have been designed to offer unsurpassed protection to your motorcycle in the unfortunate event of a crash or tip over.

Important: These Frame Sliders are designed to fit specific engine mounts of your motorcycle. This kit has separate left and right pieces (*left and right while sitting on the bike*). The shorter slider is to be used with the 180mm bolt on the right side. It is highly recommended that you refer to your service manual before performing this installation. It is also recommended that a non-permanent thread lock compound be used.

Instructions:

1. Remove the left-side engine mount bolt.
2. Install the longer piece of plastic using the new 10 x 160mm bolt supplied in this Kit
3. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.
4. Remove the right side engine mount bolt.
5. Install the shorter piece of plastic using the new 10 x 180mm bolt supplied in this Kit.
6. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.

Included in this kit:

1 LONGER SLIDER WITH SHORT ALUM. SPACER LEFT
SHORTER SLIDER WITH LONGER ALUM. SPACER RIGHT
M10X160 1.5 W/ NUT
M10X180 1.5 W/NUT

Part No. FS-64

Phone: (760-598-2105)
Web: <http://www.IntuRace.com>



Frame Sliders

Congratulations! You have just purchased the world's finest frame sliders. These sliders have been designed to offer unsurpassed protection to your motorcycle in the unfortunate event of a crash or tip over.

Important: These Frame Sliders are designed to fit specific engine mounts of your motorcycle. This kit has separate left and right pieces (*left and right while sitting on the bike*). The shorter slider is to be used with the 180mm bolt on the right side. It is highly recommended that you refer to your service manual before performing this installation. It is also recommended that a non-permanent thread lock compound be used.

Instructions:

1. Remove the left-side engine mount bolt.
2. Install the longer piece of plastic using the new 10 x 160mm bolt supplied in this Kit
3. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.
4. Remove the right side engine mount bolt.
5. Install the shorter piece of plastic using the new 10 x 180mm bolt supplied in this Kit.
6. Tighten the engine mount bolt to the factory specifications - DO NOT OVERTIGHTEN.

Included in this kit:

1 LONGER SLIDER WITH SHORT ALUM. SPACER LEFT
SHORTER SLIDER WITH LONGER ALUM. SPACER RIGHT
M10X160 1.5 W/ NUT
M10X180 1.5 W/NUT

Part No. FS-64

Phone: (760-598-2105)
Web: <http://www.IntuRace.com>